

## **Infratower IHA30xP**

### **Infracflex Tour IHA30xP**



GB ... 2

SE ... 4

FR ... 6

DE ... 8

## ASSEMBLY AND OPERATING INSTRUCTIONS

*Dear Customer, please read the following information carefully before using the appliance for the first time for your own safety and to ensure correct use.*

### SAFETY INFORMATION

- Only connect the appliance to a properly installed socket-outlet with earthing contact. Possibly a slow-blow C-fuse is necessary if you experience problems by switching on to overloaded fuses.
- Only connect the appliance to a.c. mains as specified on the rating plate.
- Never touch live parts! Danger to life!
- Never operate the appliance with wet hands! Danger to life!
- Never use the appliance if the appliance or cord is damaged. Risk of injury!
- Do not store or use any flammable materials or sprays in the vicinity of the appliance when the appliance is in use. Fire hazard!
- Do not use the appliance in flammable atmospheres (e.g. in the vicinity of combustible gases or spray cans)! Explosion and fire hazard!!
- Important! Do not insert any foreign objects into the appliance openings! Risk of injury (electric shock) and damage to the appliance!
- Attention! Do not look longer time into the light!
- Attention! The unit complete becomes very hot when the appliance is in use! Place the appliance so that it cannot be touched by accident. Risk of burns!
- Do not place any items of clothing, hand towels or similar over the heater to dry. Risk of overheating and fire hazard!
- The appliance must not be adjusted while it is in use! Risk of burns! Allow the appliance to cool down before adjusting the position.
- The appliance is not intended for use by young children or infirm persons without supervision! Young children should be supervised to ensure that they do not play with the appliance!
- The socket-outlet must be accessible at all times to enable the mains plug to be

disconnected as quickly as possible!

- These instructions for use belong to the appliance and must be kept in a safe place. When changing owners, these instructions must be surrendered to the new owner!
- The appliance must be allowed to cool down before being carried and stored!

### NOTICE

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved
- Children shall not play with the appliance
- Cleaning and user maintenance shall not be made by children without supervision
- The instructions shall include the substance of the following:
- Children of less than 3 years should be kept away unless continuously supervised.
- Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.

**CAUTION — Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.**

### LOCATION

- The radiating element is designed for use in upright standing position only.
- A minimum distance of 150 cm must be maintained between the front grille and flammable items (e.g. curtains), walls and other structures.
- The equipment must be placed on solid and

- even underground (danger of downfall)!
- Place the cable carefully to avoid the danger of stumbling.
- As the appliance radiates heat, no objects such as furniture should be placed between the appliance and the person using the appliance!
- Do not use the heater with a programmer, timer, separate remote-control system or any other device that switches the heater on automatically, since a fire risk exist if the heater is covered or positioned incorrectly.

### POWER CORD

- The power cord must not come into contact with hot appliance parts!
- Never pull the plug out of the socket at the cord! Never move the appliance by pulling at the cord or use the cord for carrying purposes!
- Do not coil the cord around the appliance! Do not use the appliance with the cord coiled!
- Do not crush the cord or drag it over sharp edges or place it over heated hotplates or naked flames!
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard

### USING THE APPLIANCE

- After switching on the appliance for the first time and following extended periods on non-use, the appliance may smell for a short time.
- Both integrated heaters may be switched on and off by the two separated switches on the upper end of the unit.
- The heating output can be adjusted by the dimmer switches who adjust each heater by 50% (down) or 100% (up).
- You may not switch on both heaters at the same time, as it can blow the fuse.

### CLEANING

- First, disconnect the equipment from the power supply system!

- After the appliance has cooled down, the housing can be wiped dry.
- Do not touch the quartz rods with your fingers, since stains could build up from such a contact.
- The reflector should be cleaned regularly
- Do not use any abrasive or caustic cleaning agents!
- Never immerse the appliance in water! Danger to life!

### AFTER-SALES SERVICE

- All repairs must be referred to authorised personnel! Therefore, you should contact your specialized dealer or the customer service.
- Important! Any tampering with the appliance will invalidate the warranty.
- Repairs carried out improperly and by unqualified persons may have serious consequences for the user!

### TECHNICAL DATA

Rated voltage: 230 V/50 Hz

Rated output: 3000 W

(2 x 1500W adjustable 25, 50, 75 and 100%)

Dimensions : (LxWxD): 29 x 126 x 32 cm

Weight about: 7.3 kg

Protective system: IP24



**Main office**

Frico AB  
Industrivägen 41  
SE-433 61 Sävedalen  
Sweden

Tel: +46 31 336 86 00

mailbox@frico.se

www.frico.net

**For latest updated information and information  
about your local contact: [www.frico.net](http://www.frico.net).**